

VOOPOO

ARGUS G4




Please read the entire manual carefully before using the product.

USER MANUAL

English

Thanks for your purchase of a VOOPOO product. For the better use of all the functions of this product, please carefully read the operation notes and detailed functional instructions before your first use of this product. If you have any problem with using this product, please contact our local agent or visit our official website at www.vooipo.com.



- 7. Output Power Switching:** Short press the function button 3 times to enter adjustment mode, then each press can adjust the output power.
- 8. Charging:** Supports 5V/2A charging. It is recommended to use the Type-C cable provided by VOOPOO to charge the device.
- 9. Software Update:** Consumers can upgrade the software to the latest version on VOOPOO's official website (www.vooipo.com), which requires the specific Type-C cable provided with the VOOPOO product to connect to the computer.

Parameters

Size:	121*27.6*15.8/16.6 mm
Power Range:	5-35 W
Battery Capacity:	1650 mAh (Built-in)
Output Voltage:	3.0-4.2 V
Charging Voltage:	5 V / 2 A
Resistance Range:	0.4-3.0 Ω
E-liquid Capacity:	3.5 mL (Standard & US Version) / 2 mL (TPD Version)
Compatibility:	All the ARGUS Pod Family Cartridges

Steps

Step 1. Fill e-liquid


Uncover the filling port and fill the e-liquid in. It is recommended to keep two-thirds full.

Step 2. Install the cartridge


Insert the cartridge into the device.

Step 3. Start to use the device

Let the coil become saturated for about five minutes, and then you are free to use the device. You can adjust the airflow, resistance and wattage for an optimal vaping experience.



Interface Introduction



cartridge, named ARGUS Multi-Ohm Cartridge, and pressing the function button 2 times shortly, the device will adjust to 0.4 Ω for a strong vaping experience. Then, short press the function button two more times, it will adjust to 0.7 Ω .

Operation Instructions

- Power On:** Short press the function button 5 times.
- Adjust Power Mode:** When vaping with ARGUS Top Fill Cartridge V2 or other ARGUS cartridges available for sale, short press the button 2 times to adjust power mode (high / medium / low power selection).
- Adjust to 0.7 Ω :** When inserting the latest ARGUS cartridge, named ARGUS Multi-Ohm Cartridge, to the side marked VOOPOO on the front, you will adjust to 0.7 Ω for a rich vaping experience. Then, when flipping the cartridge to the side marked ARGUS on its reverse side, the device will adjust to 1.0 Ω for an economical vaping experience.
- Adjust to 0.4 Ω :** When inserting the latest ARGUS



Adjust to 0.7 Ω




Adjust to 0.4 Ω

5. Show Tips: Long press the function button for 3 seconds, the screen will show you the operation tips.

6. Power Off / Theme / Puff Clear / Lock / Unlock / Exit:

- Short press the button 5 times to enter the menu.
- Short press the button to select a function.
- Long press to confirm the selected function.
- When set to 'Unlock', the function button enters a simplified mode: it can only wake the screen or access the main menu. Complex operations (like other multi-press or long-press shortcuts) are disabled, and the screen will turn off while vaping.
- Press and hold the Exit to return to the home screen.



Prompt Notification



Safety Protection

Timeout Protection: 5 s	Short-Circuit Protection	Overcharge Protection
Low Battery Protection	Output Over-Current Protection	

Maintenance and Cleaning

- When using the device, you may notice occasional liquid condensation on the outside of the atomizer. This is due to the physical process where liquid atomizes and then condenses to form condensate, which is inevitable.
- In daily use, you can often use a damp paper towel to wipe the connection between the device and the atomizer to avoid poor contact.
- When a small amount of condensate is found inside the device during use, we recommend removing the atomizer, turning the device upside down, and shaking it for a few seconds.



Notes

- When the product is used with nicotine-containing e-liquids:
 - Nicotine is a highly addictive substance. No other ingredients of this product are known to be addictive.
 - Nicotine benzene [828-490-9] Toxic if swallowed. Keep out of reach of children. Wash hands thoroughly after handling. Do not breathe vapors. IF SWALLOWED: Immediately call a POISON CENTER or doctor/pharmacist. If medical advice is needed, have the product container or label at hand. Dispose of contents/container in designated place in accordance with local regulations.
- This product is not recommended for minors, non-smokers, pregnant or breast-feeding women, or anyone at risk of heart disease, depression, and asthma.
- Please keep the device away from heat, fire, and water. This device should be stored in a cool and shady environment.
- Please do not drop, throw, or immerse the device in the water.
- Please turn off or lock the device to avoid accidental firing when you carry it out.
- Please rationally use the device according to your personal situation. If discomfort occurs, please stop using it immediately.
- E-EE Recycling: This product should not be treated as household waste. Instead, it should be taken to the collection place for the recycling of electrical and electronic equipment.
- Battery Recycling: The product battery should not be treated as household waste. Instead, it should be taken to the used battery collection place for recycling.
- It is recommended to use the USB cable provided by VOOPOO to charge the device.
- If the device is not used for an extended period, it is recommended to charge regularly to prevent deep discharge!
- The ambient temperature ranges from -5 $^{\circ}\text{C}$ - 30 $^{\circ}\text{C}$, with humidity 40%-75% RH. Operating temperature of the electronic cigarette: 0 $^{\circ}\text{C}$ - 40 $^{\circ}\text{C}$.
- Disassembly is prohibited after product failure!
- Only for indoor charging, please use a UL-certified USB charger to avoid the danger of fire and explosion!

Warranty

A three-month warranty is provided. During the warranty period, we will provide maintenance and replacement services. Please note the following conditions:

- It only applies to the products registered on VOOPOO after-sales service website.
- We assume no liability for damage caused by the user's negligence or accident.
- We are not responsible for any damage that occurs during use, maintenance or modification that does not conform to the operating instructions in the manual.
- The defects not caused by processing and the appearance problems are not covered in the warranty.
- After-sales service for the coil is not provided.

Warm Prompt

Cartridge/Tank Leakage

There is a possibility of e-liquid leakage at high pressure when you travel by air. Therefore, please keep your cartridge/tank away from other important objects.

Deal with Condensate

There may be slight condensation due to the difference between indoor and outdoor temperature when you use the device. It is advisable to take out the cartridge/tank, and shake it downwards.